
Towards fully reproducible workflows





— AiiDA informatics infrastructure —

Chris Sewell & Marnik Bercx


NCCR Ventures - Open Research Data
8 May 2023 - Lausanne




Have you ever been here?




Reproducibility Crisis




Levels of reproducibility



1. Basic: reproduce analysis from final data.
2. Full reproduction of the whole procedure that created the data.



(a) $\alpha = 1$



(c) $\alpha = 0.8$

"Methods section"

Thermodynamic Stability of Sn substitution

The formation energies of Sn-substituted structures for a range of x-values have been calculated within the Density Functional Theory [1, 2] (DFT) framework, as implemented in the Vienna Ab initio Simulation Package [3–5] (VASP). The projector augmented wave [6, 7] (PAW) method was used to make a distinction between the core and valence electrons, with the standard VASP recommended choice for the number of valence electrons. The exchange-correlation energy was calculated using the SCAN+rVV10 [23, 24] functional to include the van der Waals interaction, which is especially important for a layered structure such as SnO [25]. The wave functions of the valence electrons are expanded in a plane wave basis set, using a high energy cutoff equal to 500 eV, which is advisable for structures containing oxygen. For all $2 \times 2 \times 2$ supercell calculations, a $3 \times 3 \times 3$ Monkhorst-Pack [8] mesh was used for sampling the Brillouin zone, whereas a $6 \times 6 \times 3$ and $9 \times 9 \times 7$ mesh were used for Li_2SnO_3 and SnO, respectively. Geometry optimizations were performed with a Gaussian smearing of 0.05 eV, followed by a static calculation using the tetrahedron method [9], for a precise calculation of the total energies. The convergence criterion on the electronic optimization is set at 10^{-4} eV, and 10^{-3} eV for the geometric optimization.



Data Management

- What data do you need to store?
 - Raw ingredients (input parameters, conditions, ...)
 - Process instructions (code, program versions, ...)
 - Results
- How will you store your data?
 - How easy is it for yourself or others to read?
 - How scalable does it need to be?
- How can you search through your data?
 - Have clear data schemas
 - Are there interoperable standards in your field?





- **COMPUTATIONAL SCIENCE INFRASTRUCTURE**
 - **FOR HIGH THROUGHPUT WORKFLOWS**
 - **WITH FULL DATA PROVENANCE**



Language: implemented and API in python

License: MIT open source <http://www.aiida.net/>



Source: <https://github.com/aiidateam/aiida-core>

MIT LICENSED




Scalable workflow engine



Built-in support for HPC

Automated full data provenance

Flexible plugin system



AiiDA data store

CLI/API allows for fast querying

- All data
- Immutable



```
&CONTROL
calculation = 'relax'
etot_conv_thr = 2.0000000000d-04
forc_conv_thr = 1.0000000000d-03
max_seconds = 86400
&SYSTEM
degauss = 1.0000000000d-02
ecutrho = 2.4000000000d+02
ecutwfc = 3.0000000000d+01
/
&ELECTRONS
conv_thr = 8.0000000000d-10
electron_maxstep = 80
mixing_beta = 4.0000000000d-01
/
ATOMIC_SPECIES
Si 28.085 Si.pbe-n-rrkjus_psl.1.0.0
ATOMIC_POSITIONS angstrom
Si 0.0000000000 0.0000000000
Si 1.8940738226 1.0935440313
K_POINTS automatic
5 5 0 0
CELL_PARAMETERS angstrom
3.7881476452 0.0000000000 0.0000000000
1.8940738226 3.2806320940 0.0000000000
1.8940738226 1.0935440313 3.0930096003
```

```
%verdi code show pw.x@local_direct
```


▼ Hide cell output

PK	1
UUID	43019f16-33cc-468a-99f3-b757d9b3b8bc
Label	pw.x
Description	pw.x code on local computer
Default plugin	quantumespresso.pw
Type	remote
Remote machine	local_direct
Remote absolute path	/home/docs/checkouts/readthedocs.org/user_builds/aaiida
Prepend text	export OMP_NUM_THREADS=1
Append text	

AiiDA




profile



computer




Interoperable data example - Optimade structures



AFLOW
Automatic - FLOW for Materials Discovery



MATERIALSCLOUD



OPTIMADE

Open Databases Integration
for Materials Design



REST API

Structures

GET /structures Get Structures

GET /structures/{entry_id} Get Single Structure




Python API

```
from optimade.client import OptimadeClient
client = OptimadeClient()
client.get('elements HAS "Ag" AND nsites < 2')
```



AiiDA workflows

- Python API for plugins to define workflows, to produce new data nodes
 - Workflows can wrap existing computation software
- Plugins encode, re-usable, expert knowledge




Registered plugin packages: 66

Calculations	109 plugins in 46 packages
Parsers	94 plugins in 47 packages
Data	82 plugins in 23 packages
Workflows	129 plugins in 31 packages
Console scripts	19 plugins in 14 packages
Other	94 plugins in 24 packages


AiiDA execution engine

- The AiiDA daemon
- Workers can as
- allowing for a h
- Automated inte



LUMI

- Ran 55704 Quantum ESPRESSO calculations in 12 hours
- Handled 7887 errors on the fly
- Fully optimized 15324 geometries



workflows
calculations,




Automated failure and error recovery

Every failure mode is returned
as an "exit code"

Exit codes:


```
0 The process finished successfully.
1 The process has failed with an unspecified error.
2 The process failed with legacy failure mode.
10 The process returned an invalid output.
11 The process did not register a required output.
100 The process did not have the required 'retrieved' output.
110 The job ran out of memory.
120 The job ran out of walltime.
131 The specified account is invalid.
140 The node running the job failed.
150 {message}
301 The retrieved temporary folder could not be accessed.
302 The retrieved folder did not contain the required stdout output file.
303 The retrieved folder did not contain the required XML file.
304 The retrieved folder contained multiple XML files.
305 Both the stdout and XML output files could not be read or parsed.
310 The stdout output file could not be read.
311 The stdout output file could not be parsed.
312 The stdout output file was incomplete probably because the calculation got interrupted.
320 The XML output file could not be read.
```

BaseRestartWorkChain



How to deal with failures can also be encoded in work chain.

Data consistency



What if you?

- Delete calculation C_2 ?
- Share Data D_4 ?



Data must be kept consistent!

Sharing data on materials cloud

Default records

Engineering frustrated lewis pair active sites in porous organic scaffolds for catalytic CO₂ hydrogenation

DOI 10.24435/materialscloud:31-wz

AiiDA-generated records

A Standard Solid State Pseudopotentials (SSSP) library optimized for precision and efficiency



DOI 10.24435/materialscloud:f3-ym



CalcJobNode

JOB ID: 2570313

SCHEDULER STATE: DONE

REMOTE WORKING DIRECTORY: /scratch/snx3000/marrazzo/aiida_run/14/42/ba1a-88bc-494d-8d97-cfa5c295ca66

INPUT FILES

- aiida.in
- _aiidasubmit.sh
- _aiida/calcinfo.json
- _aiida/job_tmpl.json

OUTPUT FILES

- aiida.out
- _scheduler-stderr.txt
- _scheduler-stdout.txt
- data-file.xml

Node metadata

CUSTOM_SCHEDULER_COMMANDS: #SBATCH --constraint=cpu #SBATCH --account=pr09


EXIT_STATUS: 0

AiiDA Provenance Browser

Click on node to browse, drag to animate



MATERIALSCLOUD




- Findable
- Accessible
- Interoperable
- Reusable

Materials Cloud 3D section



901,210
Experimental
structures

CifCleanWorkChain



- [1] <https://wiki.crystallography.net/cod-tools/>
[2] <https://www.materialscloud.org/work/tools/seekpath>
[3] <https://pymatgen.org/>

858,296 Structures


Remove non-stoichiometric
compounds

pymatgen[3]
StructureMatcher

Remove molecular
crystals from COD

84,064 Structures

Materials Cloud 3D section




Materials Cloud 3D section

<https://mc3d.materialscloud.org/>

Materials Cloud three-dimensional crystals database (MC3D)

DOI: [10.24435/materialscloud:rw-t0](https://doi.org/10.24435/materialscloud:rw-t0)



Curated set of relaxed three-dimensional crystal structures based on raw CIF data from the experimental databases MPDS, COD, and ICSD.

Use

About

REST API

Search for materials:

1 H

3 Li

11 Na

19 K

37 Rb

55 Cs

87 Fr

4 Be

12 Mg

20 Ca

38 Sr

56 Ba

88 Ra

21 Sc

39 Y

72 Hf

104 Rf

22 Ti

40 Zr

73 Ta

106 Db

23 V

41 Nb

74 W

107 Sg

24 Cr

42 Mo

75 Re

108 Bh

25 Mn

43 Tc

76 Os

109 Hs

26 Fe

44 Ru

77 Ir

110 Ds

27 Co

45 Rh

78 Pt

111 Rg

28 Ni

46 Pd

79 Au

112 Cn

29 Cu

47 Ag

80 Hg

113 Nh

30 Zn

48 Cd

81 Tl

114 Fl

31 Ga

49 In

82 Pb

115 Mc

32 Ge

50 Sn

83 Bi

116 Lv

33 As

51 Sb

84 Po

117 Ts

34 Se

52 Te

85 At

118 Og

35 Br

53 I

86 Rn

36 Kr

54 Xe

2 He

10 Ne

18 Ar

36 Kr

54 Xe

86 Rn

118 Og

Elements filtering mode:

☐ Include/exclude

☒ Only selected

Interact

New React frontend published!



Dr. Kristjan Eimre

CoLi₃MnNiO₆ (mc3d-22117/pbe)

Related structures

Crystals with this chemical formula mc3d-22117/pbe (spacegroup P3₁12) ▼

Structure

Interaction on

Supercell: 2 2 2

☒ Bonds ☐ Atom labels ☐ Packed cell ☐ vdW radius

Camera: x y z

Info

Bravais Lattice: hP

Space group international: P3₁12

Space group number: 151

Source

MPDS ID: S1643390

Properties


Total energy: -46814.52 eV/cell

Total magnetization: 14.46 μ B/cell

Absolute magnetization: 15.5 μ B/cell

- All structures up to 60 atoms in unit cell run
- 35,000 structures published
- Completed over 31,000 band structures

What about experimental work?





AURORA
Autonomous robotic battery
innovation platform



Beyond data: FAIR simulation access

- Open-source, robust turn-key workflows for materials properties
- Common interface among 11 quantum engines
- Easy to use, but flexible for experts, designed to be interfaced to GUIs




AiiDA and the data life cycle



MATERIALSCLOUD

- Data can be exported into AiiDA "archive".
- Easily shared on Materials Cloud.
- Can be imported: data is not duplicated!
- Can be opened on the fly for analysis.



- Demonstrating (reproducible) plan.
- Data/IO plan becomes more concrete.



- Workflows are (mostly) self-documenting.
- Plugin decided which data is stored.
- Cleaning up data is easy and consistent.

Thank you for your attention!